

## Remote control user manual

### INLAY - TOP



### INLAY - FRONT



### Remote control code matching steps:

1. Unplug the unit to power it "Off"
2. Now active pairing sequence by holding both "LIGHT" and "STOP" button at the same time for about 3 seconds, until the 5 bars underneath the Icera logo start to flash.
3. With the indicator bars now flashing. The remote is ready to be paired with the seat.
4. Plug the unit back onto the outlet to turn it back on.
5. If the remote has successfully paired with the seat. You should see the third and fourth LED bar go solid.
6. If the bars are still flashing after 20 seconds. Power off the unit and repeat the process until the seat successfully pairs with the remote.
7. If the problem persists, please contact [service@icerausa.com](mailto:service@icerausa.com) for additional assistance.